

EN CLEANING INSTRUCTIONS

Regular service compliant with the maintenance schedule is mandatory and a prerequisite for the effective use of the juice dispenser. Do not use spray water when cleaning the juice dispenser.

1. Daily cleaning

- 1 Close the valve to the concentrate bag and dispense about 0.2 L of water into an appropriate vessel.
- 2 Activate the equipment switch in order to turn off the juice dispenser. It is not necessary to disconnect the mains power plug.
- 3 In order to prevent the build-up of mould fungi, ensure to remove the residue of juice and concentrate from the drip tray, the drip grid, the underside of the door, and the splash guard. Use a mild cleaning agent to clean the equipment and rinse thoroughly.
- 4 Use a brush or vacuum cleaner to clean the exhaust and inlet air ducts of the juice dispenser. If necessary, remove the air filter from the back panel of the equipment and clean it.

2. Weekly cleaning

Use clear water to rinse the juice dispenser inside and outside. Use a cloth to wipe the dispenser dry.

3. Miscellaneous cleaning tasks

- 1 The refrigerant condenser must be thoroughly cleaned and inspected once a year by an authorized service firm.
- 2 Only clear water shall be used to clean the door seal. Never use oil or grease to treat the door seal. It will cause the seal to become porous over time. We recommend regular treatment with TALKUM. This will extend service life of the door seal. As you may obtain the door seal from the Customer Service.
- 3 Should the mixing nozzle become clogged, place your finger on the spout and press the product dispense button on the display. Some water will squirt out of the nozzle! This will clean the nozzle.
- 4 Please be advised that for hygienic reasons, the replacement of the mixing nozzle and plastic hose is necessary from time to time. We recommend this replacement to take place during the quarterly service schedule. Any contamination of this equipment will inevitably falsify the taste of the juice and may cause a health hazard! After the mixing nozzle has been cleaned thoroughly and disinfected, it can be reused.

ATTENTION!

Please unplug machine before cleaning condenser. If back panel is removed, remember to replace it. All servicing should be undertaken by an authorised person only!

